



1. Please use **NIKKEN Bushing & Push Pin for the Oil Hole Holder** ① and make the Stopper Block by yourself.

**Code No. of Bushing & Push Pin**

#40 : BK40BS-A with O-ring P12

#50 : BK50BS-A & BK50PP-A with O-ring P18

2. How to make the Stopper Block.

- Make the suitable shape to meet with the tapped holes and the dowel pin holes on your M/C.
- It's not necessary to be heat-treated.

3. The pitch between the spindle centre and the centre of the hole of stopper block has to be physically adjusted when the oil hole holder is clamped on the spindle.